

iPad at a Glance


1

iPad Overview


This guide describes iOS 8 for:

- iPad 2
- iPad (3rd generation and 4th generation)
- iPad mini (all models)
- iPad Air (all models)

iPad mini 3



iPad Air 2




Your features and apps may vary depending on the model of iPad you have, and on your location, language, and carrier. To find out which features are supported in your area, see www.apple.com/ios/feature-availability.

Note: Apps and services that send or receive data over a cellular network may incur additional fees. Contact your carrier for information about your iPad service plan and fees.

Accessories

The following accessories are included with iPad:




USB power adapter. Use with the Lightning to USB Cable or the 30-pin to USB Cable to charge the iPad battery. The size of your adapter depends on the iPad model and your region.



Lightning to USB Cable. Use this to connect iPad (4th generation or later) or iPad mini to the USB power adapter or to your computer. Earlier iPad models use a 30-pin to USB Cable.

Multi-Touch screen

A few simple gestures—tap, drag, swipe, and pinch/stretch—are all you need to use iPad and its apps.



Sleep/Wake button

You can lock iPad and put it to sleep when you're not using it. Locking iPad puts the display to sleep, saves the battery, and prevents anything from happening if you touch the screen. You still get FaceTime calls, text messages, alarms, and notifications, and can listen to music and adjust the volume.



Lock iPad. Press the Sleep/Wake button.

Unlock iPad. Press the Home button or the Sleep/Wake button, then drag the slider that appears onscreen.

For additional security, you can require a passcode to unlock iPad. Go to Settings > Touch ID & Passcode (iPad models with Touch ID) or Settings > Passcode (other models). See *Use a passcode with data protection* on page 41.

Turn iPad on. Hold down the Sleep/Wake button until the Apple logo appears.

Turn iPad off. Hold down the Sleep/Wake button for a few seconds until the slider appears onscreen, then drag the slider.

If you don't touch the screen for two minutes, iPad locks itself. You can change how long iPad waits to lock itself, or set a passcode to unlock iPad.

Set the auto-lock time. Go to Settings > General > Auto-Lock.

Set a passcode. Go to Settings > Passcode.

An iPad Smart Cover or iPad Smart Case, sold separately, can lock or unlock iPad for you.

Set your iPad Smart Cover or iPad Smart Case to lock and unlock iPad. Go to Settings > General, then turn on Lock/Unlock.

Home button

The Home button takes you back to the Home screen at any time. It also provides other convenient shortcuts.



Go to the Home screen. Press the Home button.

On the Home screen, tap an app to open it. See *Start at home* on page 21.

See apps you've opened. Double-click the Home button when iPad is unlocked, then swipe left or right.


Use Siri (iPad 3rd generation or later). Press and hold the Home button. See *Use Siri* on page 46.

You can also use the Home button to turn accessibility features on or off. See *Accessibility Shortcut* on page 123.

On iPad models with Touch ID, you can use the sensor in the Home button, instead of using your passcode or Apple ID password, to unlock iPad or make purchases in the iTunes Store, App Store, and iBooks Store. See *Touch ID* on page 42. You can also use the Touch ID sensor for authentication when using Apple Pay to make a purchase from within an app. See *Apple Pay* on page 39.
















Volume buttons and the Side Switch

Use the Volume buttons to adjust the volume of songs and other media, and of alerts and sound effects. Use the Side Switch to silence audio alerts and notifications or to prevent iPad from switching between portrait and landscape orientation. (On iPad models without a side switch, use Control Center.)



Status icons

The icons in the status bar at the top of the screen give information about iPad:

Status icon		What it means
	Wi-Fi	iPad has a Wi-Fi Internet connection. The more bars, the stronger the connection. See Connect to Wi-Fi on page 15.
	Cell signal	iPad (Wi-Fi + Cellular models) is in range of the cellular network. If there's no signal, "No service" appears.
	Airplane Mode	Airplane Mode is on—you can't access the Internet, or use Bluetooth® devices. Non-wireless features are available. See Travel with iPad on page 45.
LTE	LTE	iPad (Wi-Fi + Cellular models) is connected to the Internet over a 4G LTE network.
4G	4G	iPad (Wi-Fi + Cellular models) is connected to the Internet over a 4G network.
3G	3G	iPad (Wi-Fi + Cellular models) is connected to the Internet over a 3G network.
E	EDGE	iPad (Wi-Fi + Cellular models) is connected to the Internet over an EDGE network.
GPRS	GPRS	iPad (Wi-Fi + Cellular models) is connected to the Internet over a GPRS network.
	Do Not Disturb	Do Not Disturb is turned on. See Do Not Disturb on page 34.
	Personal Hotspot	iPad is providing a Personal Hotspot for other iOS devices. See Personal Hotspot on page 38.
	Syncing	iPad is syncing with iTunes. See Sync with iTunes on page 18.
	Activity	There is network or other activity. Some third-party apps use this icon to show app activity.
	VPN	iPad is connected to a network using VPN. See Network access on page 145.
	Lock	iPad is locked. See Sleep/Wake button on page 10.
	Alarm	An alarm is set. See Chapter 14, Clock , on page 90.
	Screen orientation lock	Screen orientation is locked. See Change the screen orientation on page 23.
	Location Services	An app is using Location Services. See Privacy on page 40.
	Bluetooth®	<i>Blue or White icon:</i> Bluetooth is on and paired with a device, such as a headset or keyboard. <i>Gray icon:</i> Bluetooth is on and paired with a device, but the device is out of range or turned off. <i>No icon:</i> Bluetooth is not paired with a device. See Bluetooth devices on page 39.
	Bluetooth battery	Shows the battery level of a supported paired Bluetooth device.
	Battery	Shows the battery level or charging status. See Charge and monitor the battery on page 44.